



HYTORC ICE-P7

PRESSURE IN PSI	PRESSURE/TORQUE CONVERSION CHART			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	117	16	159	104
1600	125	17	170	110
1800	141	20	191	124
2000	158	22	214	138
2200	174	24	236	152
2400	190	26	258	166
2600	206	28	279	179
2800	222	31	301	193
3000	238	33	323	207
3200	254	35	344	221
3400	270	37	366	235
3600	286	40	388	248
3800	302	42	410	262
4000	318	44	431	276
4200	334	46	453	290
4400	351	49	476	304
4600	367	51	498	317
4800	383	53	519	331
5000	399	55	541	345
5200	415	57	563	359
5400	431	60	584	373
5600	447	62	606	386
5800	463	64	628	400
6000	480	66	651	414
6200	496	69	673	428
6400	512	71	694	442
6600	529	73	717	455
6800	545	75	739	469
7000	561	78	761	483
7200	578	80	784	497
7400	594	82	805	511
7600	610	84	827	524
7800	627	87	850	538
8000	643	89	872	552
8200	659	91	894	566
8400	676	93	917	580
8600	692	96	938	593
8800	708	98	960	607
9000	725	100	983	621
9200	741	102	1005	635
9400	757	105	1026	649
9600	773	107	1048	662
9800	790	109	1071	676
10000	806	111	1093	690

This chart supercedes all prior version regarding this tool 03/31/2008

Southwest Texas	West Texas	Main Office	Southeast Texas	Central & East Texas
4802 Baldwin Blvd. Corpus Christi 78408 361-888-5080	3508 S County Rd 1290 Odessa, TX 78765 432-561-8481	12420 Texaco Rd Houston, TX 77013 713-453-6677	2484 W Cardinal #4 Beaumont, TX 77705 409-840-9699	7900 Rodeo Trl. #500 Mansfield, TX 76063 682-334-2679